










FLOYD

How to Assemble:

The Sit-to-Stand Desk

FLOYD


Components: The Sit-to-Stand Desk

| | |
|---|---|
| 1x Base Unit | 2x Screws (A) |
|  |  |
| | 8x Covers (B) |
| |  |
| | 8x Small Threaded Bolts (C) |
| |  |
| 1x Desk Top (47", 59" or 70") | 2x Large Threaded Bolts (D) |
|  |  |
| 4x Zip Ties | 1x #6 Hex Tool (F) |
|  |  |
| | 1x #3 Hex Tool (E) |
| |  |

NOTE: You'll also need: a #2 Phillips Head Screwdriver and a Level.

Step: 1

Remove cover, filler box, and hardware box. Inspect hardware to ensure parts are not discarded.




Pro Tip: If you're considering a return, save your packaging!

FLOYD

Step: 2

To protect base and floor, leave the base in the cardboard tray.


Remove wrap and fold legs out. Then, tighten the 4 screws on either side of each leg.



FLOYD

Step: 3


Lift legs out of tray and place on desktop, then loosen the two outer screws.



FLOYD

Step: 4


Locate the two side rails and insert them into the side of the base as shown, then re-tighten outer screws.



FLOYD

Step: 5


Next, locate the feet and attach them via the pre-inserted screws.



FLOYD

Step: 6


Then, align the base with the corresponding holes in the under side of the top and attach with 2 bolts (D) on the center rail, and 4 bolts (C) on both side rails.



FLOYD

Step: 7

Tighten the two locking pins on either side of the rail.




FLOYD

Step: 8

Attach control panel to the underside of the desk top using a #2 Philips head screw driver.

Use zip ties to secure cables underneath desk surface.


Control panel can be repositioned to reverse side of desk top. See section 3 of user manual.



FLOYD

Step: 9

With help, flip The Desk upright and use the feet at the front and back of each rail to ensure that your desk is level.





FLOYD



Step: 10

Plug in your new desk
and enjoy!

For any troubleshooting
needs, please refer to
the User Guide.



Maximum load:
120 kg / 264.5 lb



TROUBLESHOOTING

| Problem: | Suggested correction: | |
|---|---|--|
| The desk is not able to move. | Make sure all cables are connected. Unplug the desk from the wall socket for roughly one minute and reconnect. | Connect the cables. Follow install instructions and perform a reset. |
| Only one column is moving. | | Perform a rest. If there is still only one column moving, replace the moving column. |
| Both columns are moving but at different speeds. | It is possible to move the slower column by pulling or pushing. | Replace the slower moving column. |
| The desk only moves short distances. | It is not possible to move the slower column by pulling or pushing. | Replace the faster moving column. |
| The desk stops and reverses during operation. | Make sure the desk is not overloaded. | Unload the desk. If problem persists, replace power supply and handset. |
| The desk is not able to drive all the way up or all the way down. | Make sure that nothing is blocking the table movement. | Remove any obstacles. If problem persists, replace entire underframe. |
| The desk can only drive in one direction (up or down). | | Perform a reset. |
| The desk is not horizontal. | | Perform a reset. |
| During reset, only one column is moving downward. | | Perform a reset. |

WARNING ⚠

READ ALL INSTRUCTIONS **BEFORE** ASSEMBLY & USE. ADULT ASSEMBLY REQUIRED. KEEP SMALL PARTS AND PACKAGING AWAY FROM CHILDREN.

NOTES ON USE:

Keep children and others safe by following these simple rules:

Do not allow any child to play on furniture

Do not allow climbing on any piece of furniture

Do not allow hanging from any piece of furniture

Assembly:

Use extra caution when assembling and have someone assist you. Do not change the specifications or modify this product. Incorrect assembly can cause product to fail and cause personal injury. Double check that all fasteners are tightened before use. Always have someone assist you when flipping over The Desk after assembly.

Usage:

Remove all packaging before first use. Check periodically that all fasteners are securely tightened. Be aware that fasteners may become loose with prolonged use. Only meant for indoor use. Do not drag the legs across flooring. The legs and table top are not intended to be used with other components and should only be used together as a system. Do not load with more than 120 kg (264.5 lbs). Do not stand on the Sit-to-Stand Desk. Standing or leaning on the Desk may cause risk and personal injury. The Tables should only be used with all legs firmly set on level ground. Inspect fasteners and metal legs regularly. Replace if fasteners are damaged or if metal parts are worn, rusted, bent, deformed

or damaged. Do not attempt to detach legs while table is upright/standing. Use caution when moving or flipping the Desk over. Failure to observe recommended practices such as loading beyond weight capacity can result in unsafe usage conditions and product damage or personal injury.

Care:

For the birch or walnut surface, the tabletop is finished in a water-based clear coat. For daily cleaning, use a damp cloth with a dab of dish soap or vinegar. For anything tougher, use vinegar diluted in water. Wipe the table dry after cleaning, and never let standing water remain on the surface for an extended period of time. For the linoleum surface, routine cleaning is best done with 1 part dish washing liquid to 1 part water. Do NOT use window/glass cleaner or other harsh cleaning supplies on the surface, as this could damage or warp the linoleum. For minor scuffs, use Linseed Oil (boiled or unboiled). Apply the oil directly to the affected area and let sit for 5 minutes. Then, using a damp cloth, buff the area in a circular motion. Allow the area to dry completely before using. You may need to re-apply and repeat this process a few times to fully remove blemishes. For either surface type, potted house plants may leave water marks on the desk if left for an extended period of time. We suggest using watertight pots or plastic drainage trays and frequently cleaning the area under the pot. The surfaces are made from natural materials and as such may fade over time in direct sunlight.

FLOYD